

PAVD II

PERSONAL ASSISTANCE VOICE DIALER



NO MONTHLY FEES or CONTRACTS EVER!

ONE TIME PURCHASE \$ 99.99

+ sales tax/shipping-Price subject to change without notice

NEW Personal Assistance Voice Dialer II

Easiest way to keep your independence! **Easiest** way to call for help - just push a button!

Instantly calls 1-30 people YOU choose & plays your personalized emergency message.

When a call is received - press 0 and open full 2-way communication through built in speakerphone Pacemaker Safe – Waterproof – 100 to 150 Foot Range

EMERGENCY FEATURES:

- Activate a local alarm for 15 seconds to get immediate help within the house. This feature also alerts you that you have activated the system. If you accidentally activated the system, just press the panic button again to de-activate it
- The system will automatically dial in sequential order the emergency numbers you have specified (up to 30 numbers). You can select as few as 1 emergency numbers or up to 30 to call when the panic button is pressed
- Plays a 20 second user recorded emergency message over and over again while calling each number. This ensures that the receiver of the call will hear the message regardless of when they answer
- If the other party receives the call and presses '0', a 2-minute speakerphone conversation starts. This 2-minute talk time can be extended for 2 minutes over and over again as long as you want to talk
- The receiving party of the call can press 1 then 9 to immediately end the conversation and your phone line will be instantly available for an incoming call
- Panic button remote feature. Pressing the panic button will activate the alert even if the handset is off the hook Waterproof panic button. You can shower or take a bath with the panic button

DISPLAY FEATURES:

- Large backlit keys and display.
- Bright strobe light when phone rings
- Display in 11 languages (English, French, German, Spanish, Italian, Dutch, Swedish, Finnish, Danish, Polish and Portuguese)

SOUND FEATURES:

- Headset jack (2.5 mm)
- Selectable ringer volume
- Handset volume amplification and adjustment
- Speakerphone with volume control

DIALING and CALLING FEATURES:

- User recordable (20 seconds) SOS emergency outgoing message.
- Automatic dialing of 1 to 30 emergency contacts when pendant or SOS button is pressed
- Personal phonebook for 30 entries (30 number speed dial)
- Last number redial
- Three 1-touch memory buttons (one assigned to 911)
- Talking caller ID (hear your recorded label for a caller instead of their phone number (example: 'John is calling'))
- Talking keypad - hear the buttons as you press them

OTHER FEATURES:

- Battery backup in the event of power failure (4 AA Alkaline batteries required - *not included*)

Included:

- Telephone with Handset
- AC Power Adapter
- Telephone Cord
- Waterproof Panic Button (battery included)
- Instruction Manual
- 1 Year Factory Warranty
- Additional Panic Buttons - *only \$24.99*

How does it work?

When the panic button is pressed, the system dials the first number that is programmed into it. The system then waits to 'hear' a zero (0) to be pressed on the other end of the line. This tells the system a human answered the call. If the system hears a 0, it will stop calling numbers and turn on the speakerphone. If the system does not hear a 0 pressed it will hang up and call the next number in sequence. If you add 911 to the contact list (already programmed on memory button), we suggest you program 911 at the end of the call list to ensure that someone is contacted in the event of an emergency. Note: This system WILL work with VOIP systems like AT&T, Comcast digital voice, Verizon, Vonage and Magic Jack and more.

Telephone and Caller ID Features:

- FSK/DTMF Emergency Talking Caller ID Speakerphone. The system speaks the phone number when a call comes in
- Languages Selectable: English/French/German/Spanish/Italian/Dutch/Swedish/Finnish/Danish/Polish/Portuguese
- Voice Reporting: English/French/German/Spanish/Italian/Dutch
- Up to 64 Message Memories
- Wall Mountable
- Capable of dialing a 22 Digit Telephone Number. (Long distance and special calling codes are easily stored)
- 16 Digits of Name Display
- Big Buttons for Dialing. (Great for seeing the numbers so you won't miss-dial)
- Talking Buttons - (The system Speaks the numbers as you press the buttons)
- Built-in Phonebook with up to 30 Memories
- Real Time Clock Display
- 3 One-Touch Dialing Buttons on Base Console (SOS, M1 and 911)
- 5 Levels of LCD Contrast Adjustment. (Adjust the contrast of the screen for better viewing)
- Flash Time: 100/300/600ms Selectable
- Tone/Pulse Selectable
- In-Use Indicator
- Low & No Battery Indicator (4 x AA Alkaline batteries - *not included*)
- Ringer Volume Control (Adjust the volume to the level that best fits your needs. You can even turn it Off)
- Ringer Light - (Flashing light lets you see that the phone is ringing)
- Handset Volume Control (Adjust the volume up or down)
- Speakerphone Volume Control (Slide control to set the speakerphone volume at just the right level)
- LCD Back Light (Allows you to see the screen even in total darkness)
- External power: DC 9V 300mA adapter (Included)
- Panic Button frequency: 433.92 MHz (Will not interfere with any other electronics)
- Panic Button range: 100-150 Feet from base (depending on environment)
- Panic Button battery: 23A 12V Alkaline battery (*Included*)
- PRO (program) ON/OFF switch control (Protects unit from being reprogrammed accidentally)
- Answer incoming calls through speakerphone by pressing the panic button (don't have to get up to answer the phone)

Personal Assistance Voice Dialer II FAQ:

Q. What if no one answers the phone when the Personal Assistance Voice Dialer II calls?

A. The system will continue to call over-and-over until someone answers it.

Q. Can I use this system in Canada or around the world?

A. Yes, this unit will work in Canada. Yes, you can use this unit anywhere in the world. Some countries may require a power adapter for the voltage and/or a telephone jack adapter.

Q. What if I do not have a normal phone line, I have a phone line from the cable company?

A. No Problem. This unit will work with any phone line such as Verizon, Comcast, Ooma, Vonage, MagicJack?

Q. What if I only have a cell phone, can I still use this to call for help?

A. Yes, there are adapters available (Cellular Gateway). Your cell phone will need to be Bluetooth capable.

Q. Can I wear the panic button in the shower?

A. Yes, the panic button is waterproof.

Q. What happens if I forget and leave the handset off the hook?

A. You can still press the panic button and call for help and you can still receive incoming calls.

Q. What happens if the power goes out, can I still use this system to call for help?

A. The system is AC-powered with battery backup. Non-volatile memory. With the backup battery in place, even if the power goes out the system will not lose the programming and will still operate and call for help if activated



ORDER FORM

Assistive Technology Services
"Helping You Live Independently"

8023 Franklin Road
 Murfreesboro, TN, 37128
 (615) 562-0043

Billing Address Name _____ Address _____ City _____ State _____ Phone Number _____	Check if same as Billing []	Ship To Address Name _____ Address _____ City _____ State _____ Phone Number _____
---	---	---

CUSTOMER EMAIL ADDRESS	PAYMENT TERMS	DATE
	Due on receipt	

QTY	ITEM #	DESCRIPTION	UNIT PRICE	SHIPPING	UNIT TOTAL
	AtsPAVDII	Personal Assistance Voice Dialer II US shipping	\$108.99		
	AtsPAVDII	Personal Assistance Voice Dialer II Canada Shipping	\$134.86		
	AtsPAVDII	Personal Assistance Voice Dialer II Other Shipping	\$139.98		
	atsPAVDIIXP	Extra Panic Button / Pendant US Ship	\$31.86		
	atsPAVDIIXP	Extra Panic Button / Pendant Canada Shipping	\$42.94		
	atsPAVDIIXP	Extra Panic Button / Pendant other Shipping	\$44.99		
		**NOTE EXTRA PANIC BUTTON / PENDANT			
		Wrist <input type="checkbox"/> Necklace <input type="checkbox"/>			
				Subtotal	
		Only Applicable If Shipping To Tennessee		TN Sales Tax 9.75%	
		*Prices are Subject to Change without Notice		Shipping	
				Total	

Credit Card Type	Credit Card Number	Expiration Month	Expiration Year	Security Code From Back Of Card
Visa [] MC [] AmEx [] Disc []				
Name On Card	Email Address			

"May You Know The Glory Of God And May He Bless You"

If Paying By Check Please Make Checks Payable To: Assistive Technology Services